







Adaptors

Quick Selection Table 1

CODE	AD01	AD03	AD06	AD14
DIAGRAM				
FUNCTION	LV Service Fuse Operation	Bayonet/ Spindle Clamp Operation	Bayonet/ Spindle Clamp Operation	Bayonet/ Spindle Clamp Operation
TOOL END	"Pigtail" (fits PK, UK, VK series)	Aluminium docking bayonet	Aluminium docking bayonet	Aluminium docking bayonet
STICK END FITTING	Sunrise	Button	Button	Sunrise
INSULATING STICK	Universal	38 dia	32 dia	Universal



Adaptors

Quick Selection Table 2



HV Testing and Proving Dead using Modiewark Tester

CODE	AD15	AD16	AD17	AD18
DIAGRAM				
FUNCTION	HV testing and proving dead Modiewark Tester	HV testing and proving dead Modiewark Tester	HV testing and proving dead Modiewark Tester	HV testing and proving dead Modiewark Tester
TOOL END	Modiewark holder	Modiewark holder	Modiewark holder	Modiewark holder
STICK END FITTING	Sunrise	Bayonet/spindle	“Shotgun Ring” stick	Button
INSULATING STICK	Universal	Aluminium docking bayonet		32 dia



Adaptors

Quick Selection Table 3

CODE	AD09	AD35
DIAGRAM		
FUNCTION	Convert bayonet to sunrise	Checking wood crossarm for rot
TOOL END	Sunrise	Spike
STICK END FITTING	Bayonet/ Spindle	Sunrise
INSULATING STICK	Universal (Bayonet fitting)	Universal